

# INSTRUCTION BOOKLET



## OXO GOODGRIPS® Chopper



### Use & Care Booklet



### To chop in the clear cup



1. Remove white cup cap from bottom of Chopper. (Leave black and white base on bottom of cup.)
2. Turn black knob counterclockwise to release it to the up position.
3. Remove spoon from Chopper.
4. Twist white Chopper body off of clear cup.
5. Fill clear cup with nuts, herbs, half an onion, garlic cloves, etc.
6. Replace Chopper body on to cup.
7. Press black knob repeatedly until food is chopped. (Note: When initially chopping large pieces of food, such as a thick onion wedge, the knob may not easily return to the up position between chops. This is normal. Just pull up on the knob and continue chopping.)
8. Remove Chopper body to empty food. Use spoon to scoop food from cup.

### To chop on a cutting board



1. Remove white cup cap and black and white cup base from bottom of Chopper.
2. Turn black knob counterclockwise to release it to the up position.
3. Remove spoon from Chopper.
4. Place nuts, herbs, half an onion, garlic cloves, etc. in a pile on the cutting board.
5. Place Chopper and cup over food.
6. Press black knob repeatedly until food is chopped. (Note: When initially chopping large pieces of food, such as a thick onion wedge, the knob may not easily return to the up position between chops. This is normal. Just pull up on the knob and continue chopping.)

### To disassemble for cleaning



1. Twist white Chopper body off of clear cup.
2. Remove stripper from Chopper body by pulling on the tab.
3. Press black knob down and turn clockwise to lock in the down position. (Warning: Blades will be exposed. Keep hands clear of blades.)
4. While holding the white Chopper body in one hand, carefully turn the blade counterclockwise with the other hand to remove the blade cartridge from the Chopper body.
5. All parts are dishwasher safe.

### To reassemble



1. While holding white Chopper body in one hand, carefully screw in the blade cartridge clockwise to tighten.
2. Reattach the stripper to the Chopper body by sliding it over the blade. Guides on the sides of the stripper help guide it into place. (see photo)
3. Place the Chopper body back on to the clear cup.
4. If you removed the black and white cup base, reattach it to the bottom of the clear cup.
5. The white cup cap stores on the bottom of the cup.
6. The spoon hooks on to either set of drain holes on the Chopper body.
7. Press the black knob and turn it clockwise to lock it in the down position.

### To store chopped food



Store leftover chopped food in the cup, cover it with the white cup cap and refrigerate.

### Additional cups for chopping and storing ingredients

To order additional OXO GOOD GRIPS Chopper cups (with cup cap and cup base), call the OXO Consumer Care Center at (800)545.4411 or log on to [www.oxo.com](http://www.oxo.com).

### CAUTION!

The OXO GOOD GRIPS Chopper blades are very sharp. Handle them with care when using the Chopper and when cleaning the components. Do not leave the Chopper or any components within reach of children.